


## TGS 2800 XP Hedgetrimmer




### Documents

[Ignition system](#)

---

# Illustration Ignition system



## Illustration Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	58070091R	Engine stop wire				
2	1	50050127	Spring				
3	1	2501002R	Ignition coil				
4	1	3912014R	Nut				
5	1	58070133R	Flywheel				
6	1	3960100R	Screw		SN 4815069999		BT6-096-02/15
7	1	3918005R	Washer		SN 4815069999		BT6-096-02/15
8	1	61070035BR	Starter pulley		SN 4815069999		BT6-096-02/15
9	1	61070036R	Spring				BT6-096-02/15
10	1	61070079AR	Tank cap				
11	1	58070226AR	Complete tank				
12	1	58070211R	Starter assy		SN 4815069999	Rosso; Red	BT6-096-02/15
13	1	2318817R	Air purge				
14	6	3819006R	Washer		SN 4815069999		BT6-096-02/15
15	7	3801013R	Screw		SN 4815069999		BT6-096-02/15
16	1	58070054R	Starter rope				BT6-096-02/15
17	1	072700089R	Bushing				BT6-096-02/15
18	1	093500397R	Starter handle				BT6-096-02/15
19	1	3916004R	Washer				BT6-096-02/15
20	1	58070222	Air filter kit		SN 4815191469		BT6-098-06/15
21	1	58070129R	Air filter		SN 4815191469		BT6-098-06/15
22	2	3801012R	Screw		SN 4815191469		BT6-098-06/15
23	1	50010218R	Fuel filter				
24	1	58070222	Air filter kit	SN 4815191470			BT6-098-06/15
25	1	58070222	Air filter kit		SN 4815191469		BT6-098-06/15
26	1	58070225R	Fuel line			Poliuretano; Polyurethane	
27	1	2318666AR	Carburetor WT-1019A				
28	1	58070037R	Gasket				
29	1	58070172R	Fuel line				
30	2	093800060B	Screw				
31	1	58070024R	Insulator				
32	1	58070195R	Gasket				
33	2	58070224R					
34	1	61070011AR	Breather valve				
35	1	4161211R	Bush				
36	1	3073013R	Fuel line				
37	1	61070006R	Gasket				
38	3	58070196R	Spacer				
39	1	58070201	Gasket set				
40	3	3916005R	Washer				
41	1	58070179AR	Washer				
42	1	61110162BR	Bushing				
43	1	3819031R	Washer				
44	1	61370022AR	Starter pulley	SN 4815070001			BT6-096-02/15

## Illustration Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	61370023AR	Sprocket	SN 4815070001			BT6-096-02/15
46	1	50160024	Screw	SN 4815070001			BT6-096-02/15
47	1	61370237R	Spring	SN 4815070001			BT6-096-02/15
48	1	58070211R	Starter assy	SN 4815070001		Rosso; Red	BT6-096-02/15
49	1	3914003R	Nut	SN 4815191470			BT6-098-06/15
50	1	58070215R	Air filter support	SN 4815191470			BT6-098-06/15
51	1	61170016R	Air filter	SN 4815191470			BT6-098-06/15
52	1	58070216AR	Air filter cover	SN 4815191470			BT6-098-06/15
53	1	58070223R	Screw	SN 4815191470			BT6-098-06/15
54	2	3891020R	Screw				
55	2	50160218BR	Spacer				